Stealthbox®

INSTALLATION GUIDE for the

SB-GM-SLVEXT/10W6v2

(1999-2005 Chevrolet Silverado / GMC Sierra Extended Cab Trucks with full rear bench seating.) (These instructions show for both enclosures. These enclosures are sold separately)





This Stealthbox is a product which requires professional installation skills and tools.


Please read this installation guide thoroughly before beginning the project. It will guide you step by step through the installation. Several of the steps in this process may require two people to accomplish.

It is absolutely vital that the enclosure be properly mounted to the vehicle according to these instructions. Failure to mount the enclosure properly presents two problems: 1) The sub-bass performance will suffer due to the movement of the enclosure caused by the force exerted by the woofer(s) and 2) A loose enclosure presents a serious safety hazard in the event of a collision or sudden deceleration.

Please enjoy your JL Audio Stealthbox responsibly.

JL AUDIO.


Ahead of the curve



Passenger's Side

STEP 1: Remove all contents from the rear floor area.

Remove the paper backing and place the supplied wax square on the passenger's side rear floor. The middle of the wax square needs to be placed 6.5" in front of the rear bulkhead and 6.0" away from the transmission tunnel.



Driver's Side

STEP 1: Remove all contents from the rear floor area.

Remove the paper backing and place the supplied wax square on the driver's side rear floor. The middle of the wax square needs to be placed 6.5" in front of the rear bulkhead and 6.0" away from the transmission tunnel.



STEP 3: Thread in the supplied socket cup set screw into the/each enclosure, leaving about 1/2" of the treads exposed.

Make sure that the cup end of the set screw is on the outside of the enclosure.



STEP 4: Place the/each enclosure into position and press down firmly.

Remove the/each enclosure. The wax square should have an impression of the socket cup set screw.

CAUTION

Before drilling, make sure that you are not going to be drilling into any gas lines, brake lines, transmission lines, electrical wiring, transfer case(4x4 vehicles) or anything else that might cause a reduction in your weekly pay. Always wear eye protection when drilling.




STEP 5: With the use of a 1/2" drill bit and drill. Drill out the floor at the impression on the wax square(s).

Continued on Next Page →



STEP 6: Run speaker wire to the/each enclosure and attach to the speaker terminal cup. Check the woofer(s) for proper operation at this time.



STEP 7: Back out the/each socket cup set screw to expose about 1-1/2".

Place the socket cup set screw through the mounting hole that was drilled, inside the truck.

From the under side of the truck, place a supplied fender washer, flat washer, lock washer and then hex nut onto the/each socket cup set screw.

Secure tightly, using a 14mm socket and ratchet.



STEP 8: Lower the rear seat and replace all removed contents.

CONGRATULATIONS! INSTALL COMPLETE.

Included Hardware:

- 1) 3" x 3' wax Square
- 1) 3/8"-16 x 2-1/4" Socket Cup Set Screw
- 1) 3/8" x 1-1/4" Fender Washer
- 1) 3/8" Flat Washer
- 1) 3/8" Split Lock Washer
- 1) 3/8" 16 Hex Nut

Difficulty Of Installation:




Specifications:

Enclosure Type: Ported **Driver Type:** 10W6v2-D4

Nominal Impedance: 2Ω per woofer / can be rewired for 8Ω per woofer **Cont. Power Handling:** 400Watts per woofer / 800Watts for system

JL Audio recommends using a high quality amplifier such as the JL Audio 500/1 or the JL Audio 1000/1. The diagram below shows the recommended crossover, infrasonic filter and equalizer settings for either the 500/1 or the 1000/1 when being used to power your Stealthbox®.



The JL Audio 500/1 or the JL Audio 1000/1 is a very versatile audio component. Please consult the owner's manual for detailed information about installing and tuning this amplifier.

Mid/High Frequency Driver Information:

Front Location Driver Size:

6.5" Separates

Applicable JL Audio Products: TR VR XR & 7R650-CSi

cts:



Rear Location Driver Size:

4"x 6"

Applicable JL Audio Products:

TR400-CXi



Phone: 954.443.1100



www.jlaudio.com

10369 N. Commerce Pkwy, Miramar, Florida 33025-392

SB-GM-SXT/10W6v2. JL AUDIO. Inc 2006

Page 2

Sheet SKU#011199 Revision 1/12/2006

Fax: 954.443.1111